

Specifications

	ATx-005	ATx-010	ATx-420	ATRx-420
Output Signal	0-5 VDC	0-10 VDC	4-20 mA	4-20 mA
Output Limit	8.2 VDC	15 VDC	32 mA	23 mA
Frequency Range	50-60 Hz (Sinusoidal)	50-60 Hz (Sinusoidal)	20-100 Hz (Sinusoidal)	10-400 Hz (All Waveform)
Response Time (90% step change)	100 ms	100 ms	300 ms	600 ms
Accuracy	1.0% FS	1.0% FS	1.0% FS	1.0% FS
Power Supply*	None, self-powered	None, self-powered	24 VDC nom	24 VDC nom
Output Loading*	1 MΩ recommended, 100 KΩ add 1.3% error*	1 MΩ recommended, 100 KΩ add 1.3% error*	40 VDC max	35 VDC max
			< 950 Ω @ 24 VDC	< 600 Ω @ 24 VDC
	*See "Output Wiring" section. Use with 100 VA max or Class 2 power supply.			
Isolation Voltage	2200 VAC			
Case	UL 94-V-0 Flammability rated thermoplastic			
Sensing Aperture	-FF 0.54" (13.7 mm) -FT 0.74" (18.8 mm) -SP 0.85" (21.6 mm)			
Environmental	-4 to 122°F (-20 to 50°C) 0-95% RH, Non-condensing Pollution Degree 2 Altitude to 6561 ft (2000 meters)			
Torque Ratings	5-7 inch-pounds torque for models with -24L & -SP suffix; 9 inch-pounds torque for all other models.			
Listings	UL/cUL, CE			

For products intended for the EU market, the following is applicable to the CE compliance of the product:

The AT & ATR series comply with EN 61010-1 CAT III 300 Vrms max. line-to-neutral measurement category. The voltage rating of the measurement category can be improved according to the insulation characteristics given by the cable manufacturer.

Warning! Risk of Danger

Safe operation can only be guaranteed if the current transducer is used for the purpose it has been designed for and within the limits of the technical specification. When this symbol is used, it means you must consult all documentation to understand the nature of potential hazards and the action required to avoid them.



Warning! Risk of Shock

When operating the current transducer, certain parts of the module may carry hazardous live voltage (e.g. primary conductor, controlled load). The transducer should not be put into operation if the installation is not complete.



Input Maximums

MODEL	RANGE	MAXIMUM INPUT AMPS		
		CONTINUOUS	6 SEC.	1 SEC.
AT0 & ATR0	0-2A 0-5A	40	60	100
		100	125	250
AT1 & ATR1	0-10 A 0-20 A 0-50 A	80	125	250
		110	150	300
		175	215	400
AT2 & ATR2	0-100 A 0-150 A 0-200 A	200	300	600
		300	450	800
		400	500	1000

Model Number Key

AT **1 - 420 - 24L - SP**

CASE STYLE:

- FF - Solid-Core, Front Terminals¹
- FT - Solid-Core Top Terminals
- SP - Split-Core

POWER SUPPLY:

- 000 - None Required (Self Powered)²
- 24L - Nominal 24 VDC³

OUTPUT:

- 420 - 4-20 mA
- 005 - 0-5 VDC
- 010 - 0-10 VDC

RANGE:

- 0 - 2 or 5 Amps³
- 1 - 10, 20 or 50 Amps
- 2 - 100, 150 or 200 Amps

SENSOR TYPE:

- AT - AC current transducers, average responding
- ATR - AC current transducers, True RMS, 4-20 mA Output

Notes

- 1 AT Series, all outputs.
- 2 AT Series with 0-5 or 0-10 VDC output.
- 3 AT or ATR Series with 4-20 mA output.

Know Your Power



Other NK Technologies Products Include:

AC & DC Current Transducers and Switches
1φ & 3φ Voltage and Power Transducers
Current Transformers (CTs)
Ground Fault Protection Relays



NK Technologies

3511 Charter Park Drive, San Jose, CA 95136
Phone: 800-959-4014 or 408-871-7510
Fax: 408-871-7515
sales@nktechnologies.com, www.nktechnologies.com

INSTRUCTIONS



AT & ATR SERIES

AC Current Transducers

Ranges 0, 1 & 2

4-20 mA, 0-5 or 0-10 VDC Outputs
Average Responding or True RMS

Quick "How To" Guide

1. Run the wire you are monitoring through aperture.
2. Mount the sensor to a surface if needed.
3. Connect output wiring.
 - A. Use up to 14-22 AWG copper wires only rated 75°C minimum.
 - B. 0-5/10 VDC Models: Make sure output load is at least 1 MegΩ.
 - 4-20 mA Models: Make sure loop voltage is correct (see "Output Wiring" section).
4. Select Range.
 - A. Choose correct range by positioning the Range Jumper.

Description

AT Series transducers combine a current transformer and a signal conditioner into a single package. This provides higher accuracy, lower wiring costs, easier installation and save valuable panel space.

AT Series are available in solid or split core with 4-20 mA, 0-5 VDC or 0-10 VDC outputs. Select AT Series for constant speed loads or On/Off loads.

ATR Series are available in 4-20 mA output only. ATR Series provide a "True RMS" output. Select ATR Series for variable speed or SCR controlled loads.

Installation


For All Versions

Run wire to be monitored through opening in the sensor.

AT and ATR Series transducers work in the same environment as motors, contactors, heaters, pull-boxes, and other electrical enclosures. They can be mounted in any position or hung directly on wires with a wire tie. Just leave at least one inch distance between sensor and other magnetic devices.

Split-Core Versions (-SP Suffix)

Press the tab in the direction as shown to open the sensor. After placing the wire in the opening, press the hinged portion firmly downward until a definite click is heard and the tab pops out fully.



KEEP SPLIT-CORE SENSORS CLEAN.

Silicone grease is factory applied on the mating surfaces to prevent rust and improve performance. Be careful not to allow grit or dirt onto the grease in the contact area. Operation can be impaired if the mating surfaces do not have good contact. Check visually before closing.

Output Wiring

Connect control or monitoring wires to the sensor. Use up to 14-22 AWG copper wire and tighten terminals to 5-7 inch-pounds torque for models with -24L & -SP suffix, and to 9 inch-pounds torque for all other models. Be sure the output load or loop power requirements are met (see diagram at right).

Connection Notes:

- Combination screw terminals (except ATRx-SP)
- Captive screw terminals (ATRx-SP only)
- 14-22 AWG solid or stranded
- Observe polarity
- See label for ranges & jumper positions

Range Select

AT/ATR Series transducers feature field selectable ranges. The ranges are factory calibrated, eliminating time consuming and inaccurate field setting of zero or span.

1. Determine the normal operating amperage of your monitored circuit.
2. Select the range that is equal to or slightly higher than the normal operating amperage.

Trouble Shooting, 0-5 and 0-10 VDC Models

1. Sensor has no output

- Polarity is not properly matched. *Check and correct wiring polarity.*
- Monitored load is not AC or is not on. *Check that the monitored load is AC and that it is actually on.*
- Split-Core models: The core contact area may be dirty. *Open the sensor and clean the contact area.*

2. Output Signal Too Low

- The jumper may be set in a range that is too high for current being monitored. *Move jumper to the correct range.*


Trouble Shooting, 4-20 mA Models

1. Sensor has no output

- Power supply is not properly sized *Check power supply voltage and current rating.*
- Polarity is not properly matched. *Check and correct wiring polarity.*
- Split-Core models: The core contact area may be dirty. *Open the sensor and clean the contact area.*

2. Output Signal Too Low

- The jumper may be set in a range that is too high for current being monitored. *Move jumper to the correct range.*
- The load current is not sinusoidal (AT only). *Select an ATR transducer that works on distorted waveforms.*




Loop Voltage Requirements:

AT Series: $VL = 5 V + (RL \times 20 mA)$

ATR Series: $VL = 12 V + (RL \times 20 mA)$

Where: VL = Min. Loop voltage & RL = Loop Resistance



1 $M\Omega$ recommended for output load.
Add 1.3% error for 100 $K\Omega$.

- Output load too low. *Check output load, be sure it is at least 100 $K\Omega$ and preferably 1 Meg Ω .*
- Monitored current is below minimum required. *Loop the monitored wire several times through the aperture until the "sensed" current rises above minimum. Sensed Amps = (Actual Amps) x (Number of Loops). Count loops on the inside of the aperture.*

3. Output Signal is always at maximum

- The jumper may be set in a range that is too low for current being monitored. *Move jumper to the correct range.*

- Monitored current is below minimum required. *Loop the monitored wire several times through the aperture until the "sensed" current rises above minimum. Sensed Amps = (Actual Amps) x (Number of Loops). Count loops on the inside of the aperture.*

3. Sensor is always at 4 mA

- Monitored load is not AC or is not on. *Check that the monitored load is AC and that it is actually on.*

4. Output Signal is always at 20 mA

- The jumper may be set in a range that is too high for current being monitored. *Move jumper to the correct range.*