

The ACI Series AmpFlasher is a self-powered sensor which gives a flashing LED indication of current flow through a conductor. It is intended for use in control panel applications to give a quick visual confirmation of current flow and identify live conductors.


Specifications

Model	ACI - 0.5 - L ACI - 0.5 - P
Current Range	0.5A -- 100A
Description	Current Indicator, 0.5A trip, flashing LED
Aperture ID	0.32" ID
Case	UL94 V0 Flammability Rated
Environmental	-4 to 122°F (-20 to 50°C), 0-95% RH
Frequency	50 -- 400 Hz
Listings	UL 508

Installation

The ACI Current Indicator is mounted by sliding the unit directly onto the current-carrying conductor. It may be secured with a tie wrap or with multiple turns of the conductor. For remote mounting of the LED (ACI-0.5-P), drill a hole 0.25" into the panel (up to 0.125" thickness), snap in the clip from the front. Slip the ring over the LED, snap the LED into the clip and snap the ring onto the back of the clip.

p/n 390200003 Rev 03



The ACI Series AmpFlasher is a self-powered sensor which gives a flashing LED indication of current flow through a conductor. It is intended for use in control panel applications to give a quick visual confirmation of current flow and identify live conductors.


Specifications

Model	ACI - 0.5 - L ACI - 0.5 - P
Current Range	0.5A -- 100A
Description	Current Indicator, 0.5A trip, flashing LED
Aperture ID	0.32" ID
Case	UL94 V0 Flammability Rated
Environmental	-4 to 122°F (-20 to 50°C), 0-95% RH
Frequency	50 -- 400 Hz
Listings	UL 508

Installation

The ACI Current Indicator is mounted by sliding the unit directly onto the current-carrying conductor. It may be secured with a tie wrap or with multiple turns of the conductor. For remote mounting of the LED (ACI-0.5-P), drill a hole 0.25" into the panel (up to 0.125" thickness), snap in the clip from the front. Slip the ring over the LED, snap the LED into the clip and snap the ring onto the back of the clip.

p/n 390200003 Rev 03



The ACI Series AmpFlasher is a self-powered sensor which gives a flashing LED indication of current flow through a conductor. It is intended for use in control panel applications to give a quick visual confirmation of current flow and identify live conductors.


Specifications

Model	ACI - 0.5 - L ACI - 0.5 - P
Current Range	0.5A -- 100A
Description	Current Indicator, 0.5A trip, flashing LED
Aperture ID	0.32" ID
Case	UL94 V0 Flammability Rated
Environmental	-4 to 122°F (-20 to 50°C), 0-95% RH
Frequency	50 -- 400 Hz
Listings	UL 508

Installation

The ACI Current Indicator is mounted by sliding the unit directly onto the current-carrying conductor. It may be secured with a tie wrap or with multiple turns of the conductor. For remote mounting of the LED (ACI-0.5-P), drill a hole 0.25" into the panel (up to 0.125" thickness), snap in the clip from the front. Slip the ring over the LED, snap the LED into the clip and snap the ring onto the back of the clip.

p/n 390200003 Rev 03



The ACI Series AmpFlasher is a self-powered sensor which gives a flashing LED indication of current flow through a conductor. It is intended for use in control panel applications to give a quick visual confirmation of current flow and identify live conductors.


Specifications

Model	ACI - 0.5 - L ACI - 0.5 - P
Current Range	0.5A -- 100A
Description	Current Indicator, 0.5A trip, flashing LED
Aperture ID	0.32" ID
Case	UL94 V0 Flammability Rated
Environmental	-4 to 122°F (-20 to 50°C), 0-95% RH
Frequency	50 -- 400 Hz
Listings	UL 508

Installation

The ACI Current Indicator is mounted by sliding the unit directly onto the current-carrying conductor. It may be secured with a tie wrap or with multiple turns of the conductor. For remote mounting of the LED (ACI-0.5-P), drill a hole 0.25" into the panel (up to 0.125" thickness), snap in the clip from the front. Slip the ring over the LED, snap the LED into the clip and snap the ring onto the back of the clip.

p/n 390200003 Rev 03



The ACI Series AmpFlasher is a self-powered sensor which gives a flashing LED indication of current flow through a conductor. It is intended for use in control panel applications to give a quick visual confirmation of current flow and identify live conductors.


Specifications

Model	ACI - 0.5 - L ACI - 0.5 - P
Current Range	0.5A -- 100A
Description	Current Indicator, 0.5A trip, flashing LED
Aperture ID	0.32" ID
Case	UL94 V0 Flammability Rated
Environmental	-4 to 122°F (-20 to 50°C), 0-95% RH
Frequency	50 -- 400 Hz
Listings	UL 508

Installation

The ACI Current Indicator is mounted by sliding the unit directly onto the current-carrying conductor. It may be secured with a tie wrap or with multiple turns of the conductor. For remote mounting of the LED (ACI-0.5-P), drill a hole 0.25" into the panel (up to 0.125" thickness), snap in the clip from the front. Slip the ring over the LED, snap the LED into the clip and snap the ring onto the back of the clip.

p/n 390200003 Rev 03



The ACI Series AmpFlasher is a self-powered sensor which gives a flashing LED indication of current flow through a conductor. It is intended for use in control panel applications to give a quick visual confirmation of current flow and identify live conductors.

Specifications

Model	ACI - 0.5 - L ACI - 0.5 - P
Current Range	0.5A -- 100A
Description	Current Indicator, 0.5A trip, flashing LED
Aperture ID	0.32" ID
Case	UL94 V0 Flammability Rated
Environmental	-4 to 122°F (-20 to 50°C), 0-95% RH
Frequency	50 -- 400 Hz
Listings	UL 508

Installation

The ACI Current Indicator is mounted by sliding the unit directly onto the current-carrying conductor. It may be secured with a tie wrap or with multiple turns of the conductor. For remote mounting of the LED (ACI-0.5-P), drill a hole 0.25" into the panel (up to 0.125" thickness), snap in the clip from the front. Slip the ring over the LED, snap the LED into the clip and snap the ring onto the back of the clip.

p/n 390200003 Rev 03

